



Installation UF-80 Device Driver for Windows Vista

This manual is the process of install driver on Windows Vista. Follow this process.


1. After attaching the device, you can watch this window. You should select the first option '**Locate and install driver software**'.



2. After selecting first option, you can watch the question about connecting Windows update sites, and you should select the third option '**Don't search online**'.




3. You can watch the 'insert the disc', at that time you should select the second option '**I don't have the disc, Show me other options.**'




4. For searching driver software files, select the second option.



5. After searching the path(device driver software), click the Next button.



6. For install the driver, select the Second option 'Install this driver software anyway'.



7. If you follow this process, your device would be installed. After install SDP application, you can use UF-80 Presenter.